



AMERICAN RUNNER RUNNING BOARD

Part #: 128100 VEHICLE BRACKET CONFIGURATION

USE BRACKET# 1,2,3,5 FOR:

Chevy/GMC

96-08 Express/Savana Full Size Van (Regular Wheel Base)



Use bracket #1,2,3 on driver and passenger front and mounted at an angle. See above.



Use bracket #1,2,3 for the remaining installation on driver side only. See above.



Use bracket #1,2,5(2) for the remaining installation on the passenger side only. See above.

USE BRACKET #1,2,5

Dodge

06-08 Ram Mega Cab

07-08 Ram Quad Cab SLT New Body Style (wheel-to-wheel)

03-08 Sprinter Wagon 140"/144" wheel base

Ford

92-08 Full Size Van



When installing bracket #2 to main frame, check for clearance of AC lines, brake lines etc. behind the main frame before drilling.

Toyota

07-08 Tundra Double Cab (long bed wheel-to-wheel)