



AMERICAN RUNNER RUNNING BOARD

Part #: 128118 VEHICLE BRACKET CONFIGURATION

USE BRACKET# 1,2,3,5 FOR:

Chevy/GMC

96-08 Express/Savana Full Size Extended Van, (long wheel base)



Use bracket #1,2,3 on driver and passenger front, mounted at an angle. See above.



Use bracket #1,2,3 for the remaining installation on driver side only. See above.



Use bracket #1,2,5 for the remaining installation on the passenger side only. See above.

USE BRACKET# 1,2,5 FOR:

Dodge

06-07 Ram Mega Cab (wheel-to-wheel)

05-07 Sprinter Wagon 158" wheel base

Toyota

07-08 Tundra Double Cab (long bed wheel-to-wheel)