

INSTALLATION INSTRUCTIONS

ONKI MODULAR BRUSH GUARD – PART # 243725
02-06 CHEVY Tail Blazer/Trail Blazer EXT

Parts List *(Please check that you have all the parts listed below before you start installing)*

Quantity	Brush guard installation hardware
2	Mounting brackets
6	½" X 40 hex head bolts (use on self threaded holes on bracket)
18	1/2" SAE washers
6	M12X40 (19mm hex head bolts)
6	M12 Nylon lock nuts (19mm socket nuts)
12	½" SAE washers

Installation of Mounting Frame Brackets & Brush Guard

1. Identify the left and right brackets to be used (D for driver side / P for passenger side).



2. Remove factory lower valance.
3. Align bracket to frame, use a 5/8" drill bit to enlarge existing holes.
4. Install bracket to frame with the supplied ½"x40 hex bolts and washers to threaded holes on bracket.
5. Repeat step 2 thru 4 for the opposite side.
6. With brackets in place, place valance on top of the brackets, mark and cut valance to clear brackets.
7. Reinstall valance.
8. With the help of another person, align and position the Brush Guard onto the installed brackets and securely tighten with the supplied M12X40 hex bolts, washers, and nuts.
9. Finally, make sure all nuts, bolts and brackets are tightened.

**For technical support, please call
1-510-567-8875**