

# INSTALLATION INSTRUCTIONS

ONKI MODULAR BRUSH GUARD – PART # 363758  
02-05 DODGE RAM 1500

**Parts List** *(Please check that you have all the parts listed below before you start installing)*

Quantity	Brush guard installation hardware
2	Mounting brackets
10	M12X40(19mm hex head bolts)
10	M12 Nylon lock nuts (19mm socket nuts)
20	½" SAE washers
2	Swing away grille locks

## Installation of Mounting Frame Brackets & Brush Guard

1. Remove plastic bumper filler.
2. Identify the left and right brackets to be used (D for driver side / P for passenger side).
3. Install bracket to the 4 pre-drilled holes with the supplied M12X40 bolts and nuts.



4. Repeat step 2 thru 3 on the opposite side.
5. With the help of another person, align and position the Brush Guard onto the installed brackets and securely tighten with the supplied M12X40 hex bolts, washers, nuts, and swing away locks.
6. Make sure all nuts, bolts and brackets are tightened.
7. Trim to fit and reinstall plastic bumper filler.

**For technical support, please call  
1-510-567-8875**

