

INSTALLATION INSTRUCTIONS

ONKI MODULAR BRUSH GUARD – PART # 363759
06-07 DODGE RAM 1500

Parts List *(Please check that you have all the parts listed below before you start installing)*

Quantity	Brush guard installation hardware
2	Mounting brackets w/ 2 additional support braces
10	M2 X 40(19mm hex head bolts)
10	M12 Nylon lock nuts (19mm socket nuts)
20	½" SAE washers
2	Swing away grille locks

Installation of Mounting Frame Brackets & Brush Guard

1. Identify the left and right brackets to be used (D for driver side / P for passenger side).
2. Installation of the brackets may require removal and/or notching of the bumper skirt. Look for the 2 outer bolts attaching the bumper assembly to the frame (Photo # 1). Remove the original nuts, put the bracket onto the 2 bolts and tighten down with the original nuts previously removed.



Photo # 1 (Driver Side)



Photo # 2 (Driver Side)

3. Look for the hole on the lower part of the bracket arm attached to the bumper assembly. Install the additional support brace to this hole using the nuts, bolts, and washers provided. Use the original nut to the outside of the hole on the bracket to attach the support brace to the bumper assembly (Photo # 2).
4. Repeat step accordingly for the passenger side.
5. Remove the acorn head bolts attaching the bottom bar to the Brush Guard.
6. Align and position the Brush Guard onto the installed brackets and securely tighten the bottom hole with the acorn head bolt originally holding the bottom bar in place. The Brush Guard uprights should be on the inside of the brackets. Tighten the acorn head bolt just enough for the Brush Guard to be tilted forward, away from the hood of the vehicle.
7. Tighten down the whole Brush Guard with the 2 quick release latches provided.
8. Make sure all nuts, bolts and brackets are tightened.
9. Trim to fit and reinstall plastic bumper skirt if necessary.

**For technical support, please call
1-510-567-8875**