

INSTALLATION INSTRUCTIONS

ONKI MODULAR BRUSH GUARD – PART # 363766
06-07 DODGE RAM 2500/3500 HD & All MEGA CABS

Parts List *(Please check that you have all the parts listed below before you start installing)*

Quantity	Brush guard installation hardware
2	Mounting brackets
10	M2 X 40(19mm hex head bolts)
10	M12 Nylon lock nuts (19mm socket nuts)
20	½" SAE washers
2	Swing away grille locks

Installation of Mounting Frame Brackets & Brush Guard

1. Identify the left and right brackets to be used (D for driver side / P for passenger side).
2. **Vehicles without tow hooks:** Remove plastic bumper filler.
3. Attach bracket to the tow hook location, enlarging factory holes is needed to install bracket with the supplied M12X40 bolts and nuts.



4. **Vehicles with tow hooks:** Remove tow hooks (special socket required) by removing the factory bolts.
5. Attach bracket to the tow hook location and reinstall tow hook with factory bolts starting at the lower outside corner with the special socket.
6. Repeat step accordingly for the opposite side.
7. Align and position the Brush Guard onto the installed brackets and securely tighten with the supplied M12X40 hex bolts, washers, nuts, and swing away locks.
8. Make sure all nuts, bolts and brackets are tightened.
9. Trim to fit and reinstall plastic bumper filler.

**For technical support, please call
1-510-567-8875**