

# INSTALLATION INSTRUCTIONS

ONKI MODULAR BRUSH GUARD – PART # 367393  
03-06 FORD Expedition

**Parts List** *(Please check that you have all the parts listed below before you start installing)*

Quantity	Brush guard installation hardware
2	Mounting brackets
2	1" X 4" nut plates
10	M12X40 (19mm hex head bolts)
6	M12 Nylon lock nuts (19mm socket nuts)
18	½" SAE washers

Note: Tow hooks will be eliminated, if equipped.

## Installation of Mounting Frame Brackets & Brush Guard

1. Identify left and right brackets to be used (D for driver side / P for passenger side).
2. **For vehicles equipped with tow hooks:**



- Remove factory tow hooks and discard. Make sure to keep the factory bolts and nut plates in the same locations for the mounting bracket to be installed.
3. **For vehicles not equipped with tow hooks:**  
Insert the supplied nut plate thru the side of the main frame to the bottom of the factory pre-drill holes where the nut plate holes will align with the factory holes.
  4. Attach bracket and fasten with the removed factory bolts to the factory nut plate or the inserted nut plate with the supplied M12 X 40 hex bolt and washers.
  5. Repeat appropriate steps on the opposite side.
  6. With the help of another person, align and fasten the Brush Guard to the installed brackets with the supplied M12X40 hex bolts and nuts.
  7. Now, securely tighten all nuts, bolts.

**For technical support, please call  
1 (510) 567-8875**