

# INSTALLATION INSTRUCTIONS

ONKI MODULAR AEGIS GUARD – PART # 367398A  
04-07 FORD F150 Super Cab/Crew Cab 2/4WD

**Parts List** (*Please check that you have all the parts listed below before you start installing*)

Quantity	Brush guard installation hardware
2	Mounting brackets
2	1" X 4" nut plates
6	M12X40 (19mm hex head bolts)
2	M12 Nylon lock nuts (19mm socket nuts)
8	½" SAE washers
2	Swing away grille locks

**Note:** 2WD requires bumper fascia notching.

## Installation of Mounting Frame Brackets & Aegis Guard

1. Identify left and right brackets to be used (D for driver side / P for passenger side).
2. **For vehicles equipped with tow hooks:**



- Remove factory tow hooks (tow hooks to be reinstalled later). Make sure to keep the factory bolts and nut plates in the same locations for the mounting brackets to be installed. Go to step 4.
3. **For vehicles not equipped with tow hooks.** (Notching bumper tow hooks indentation is required)  
Mark and notch out tow hook indentations to install brackets. Insert the supplied nut plate thru the side of the main frame to the bottom of the factory pre-drilled holes where the nut plate holes will align with the factory holes and fasten with the supplied hex bolts and washers. Repeat on the opposite then go to step 6.
  4. Attach bracket and the tow hook to the main frame. Fasten with the removed factory bolts thru the factory nut plate.
  5. Repeat step 2 and 4 on the opposite side.
  6. With the help of another person, align and fasten the Aegis Guard to the installed brackets with the supplied M12X40 hex bolts, nuts and swing away grille locks.
  7. Now, securely tighten all nuts and bolts.

**For technical support, please call  
1 (510) 567-8875**