

INSTALLATION INSTRUCTIONS

ONKI MODULAR AEGIS GUARD – PART # 367466A

00-05 FORD Excursion
99-07 FORD F-250/350/450/550 Super Duty

Parts List *(Please check that you have all the parts listed below before you start installing)*

Quantity	Description
2	Mounting brackets
6	M12X40 (19mm hex head bolts)
6	M12 Nylon lock nuts (19mm socket nuts)
12	½" SAE washers

Installation of Mounting Frame Brackets & Aegis Guard

1. Identify the left and right brackets to be used (D for driver side / P for passenger side).
2. To install main mounting brackets, locate the 2 factory bolts on each side of the tow hooks. Remove 2 bolts one side at a time, (Do not remove both sides at the same time, front bumper cover can be dislocated from frame) then install bracket by using the removed factory bolts and retaining plate from the back.



Passenger side shown here.

3. Repeat step 2 on the opposite side.
4. With the help of another person, align the Aegis Guard to the installed brackets by using supplied M12X40 hex bolts.



Driver side shown here

5. Securely tighten all nuts and bolts.

**For technical support, please call
1-510-567-8875**