

INSTALLATION INSTRUCTIONS

ONKI MODULAR BRUSH GUARD – PART # 367778
01-05 FORD Explorer Sport 2Dr
00-05 FORD Explorer Sport Trac

Parts List *(Please check that you have all the parts listed below before you start installing)*

Quantity	Description
2	Mounting brackets
2	1" X 4" nut plates
10	M12X40 (19mm hex head bolts)
6	M12 Nylon lock nuts (19mm socket nuts)
16	½" SAE washers

Installation of Mounting Frame Brackets & Brush Guard

1. If your vehicle is equipped with tow hooks, remove the mud guard from underneath the vehicle to have better access to the tow hook mounting bolts and remove the tow hooks. If your vehicle is not equipped with tow hooks it is not necessary to remove the mudguard.
2. Identify left and right brackets to be use (D for driver side / P for passenger side).
3. Fasten the mounting bracket to the vehicle's tow hook location and then tow hook with supplied M12X40 hex head bolts. Vehicles without tow hooks, insert the supplied nut plate thru the oblong hole (one on each side) and align to the existing holes on the bottom of the main frame and fasten bracket with the supplies M12 X 40 hex bolts.



4. Repeat steps on the opposite side.
5. With the help of another person, align and position the Brush Guard to the installed mounting bracket and fasten with the supplied M12 X 40 hex bolts, nuts and washers
6. Secure and tighten all nuts and bolts.

For technical support, please call
1-510-567-8875