

INSTALLATION INSTRUCTIONS

ONKI MODULAR BRUSH GUARD – PART # 526830
03-06 LAND ROVER Range Rover

Parts List (Please check that you have all the parts listed below before you start installing)

Quantity	Brush guard installation hardware
2	Mounting brackets
2	Support L brackets
2	M6X31mm replacement screws
2	M8X31mm bolts
2	M8 Nylon lock nuts
4	3/8" washers
2	1 ½" x 2 ½" threaded nut plates
10	M12X40(19mm hex head bolts)
6	M12 Nylon lock nuts (19mm socket nuts)
18	½" SAE washers

Note: Brush Guard may interfere with front bumper sensors.

Installation of Mounting Frame Brackets & Brush Guard

1. Identify the left and right brackets to be used (D for driver side / P for passenger side).
2. Remove skid panel to get access. Under the skid panel, there are two ½" holes on the frame bracket located at each end. Mark skid panel and cut skid panel to clear brackets to be installed.



3. Install bracket by attaching it to the bottom of the frame and insert the supplied nut plate from the top of the existing holes on the frame bracket, fasten with supplied M12X40 hex bolts, washers thru nut plate.
4. Repeat steps on the opposite side.
5. With the help of another person, align and position the Brush Guard onto the installed brackets and securely tighten with the supplied M12x40 Hex Bolts, washers, and nuts.
6. On the lower bumper opening, locate and remove two M6 Philips screws (one on each side). Install support L bracket between bumper and bumper bracket and connect to brush guard main plate, loosely fasten supplied replacement M6X31mm screw and M8X31mm bolts and nuts.



7. Repeat step 6 on the opposite side.
8. Inspect and secure all nuts, bolts and brackets. Reinstall skid panel.

For technical support, please call
1-510-567-8875