

INSTALLATION INSTRUCTIONS

ONKI MODULAR BRUSH GUARD – PART # 539470
98-06 LEXUS LX 470

Parts List *(Please check that you have all the parts listed below before you start installing)*

| Quantity | Brush guard installation hardware |
|----------|--|
| 2 | Mounting brackets |
| 2 | 1 ½" x 1 ½" Spacers |
| 2 | M12X140 (19mm hex head bolts) |
| 2 | M12x40 (19mm hex head bolts) |
| 4 | M12 Nylon lock nuts (19mm socket nuts) |
| 6 | ½" SAE washers |
| 2 | Swing away grille locks |

Installation of Mounting Frame Brackets & Brush Guard

1. Identify the left and right brackets to be used (D for driver side / P for passenger side).
2. Remove factory tow hook and bolts.
3. Install bracket to mainframe by reinstalling factory tow hook and front bolt thru bracket, insert spacer in rear of tow hook and reinstall factory bolt.



4. Insert the supplied M12x140 bolt from bottom of bracket thru the factory holes on mainframe and fasten with supplied nut and washer
5. Repeat step 2 and 4 on the opposite side.
6. With the help of another person, align and position the Brush Guard onto the installed brackets and securely tighten with the supplied M12X40 Hex Bolts, washers, and nuts.
7. Install supplied 2 swing away grille locks.



8. Finally, make sure all nuts, bolts and brackets are tightened.

**For technical support, please call
1-510-567-8875**