

INSTALLATION INSTRUCTIONS

ONKI MODULAR BRUSH GUARD – PART # 637686
02-06 MERCURY Mountaineer

Parts List (Please check that you have all the parts listed below before you start installing)

Quantity	Description
2	Mounting brackets
2	1" X 4" nut plates
10	M12X40(19mm hex head bolts)
6	M12 Nylon lock nuts (19mm socket nuts)
20	½" SAE washers

Installation of Mounting Frame Brackets & Brush Guard

Note: Installation requires cutting on lower air dam strip in order to install brackets.

1. Identify left and right brackets to be used (D for driver side / P for passenger side).
2. Underneath the front bumper, locate the oblong holes underneath the main frame (one on each side).
3. Hold and align bracket up to the predrilled holes and mark the lower air dam strip to be cut approx. 1"(spacing between main plates is 29")
Driver side shown below.



4. Insert the supplied nut plate thru the oblong hole (one on each side) and align to the existing holes on the bottom of the main frame.



5. Install bracket to nut plate and fasten with supplied M12 X40 hex bolt.
6. Repeat steps 2 thru 5 on the opposite side.
7. With the help of another person, align and position the Brush Guard to the installed mounting bracket and fasten with the supplied M12 X 40 hex bolts, nuts and washers
8. Secure and tighten all nuts and bolts.

**For technical support, please call
1-510-567-8875**