

INSTALLATION INSTRUCTIONS

ONKI MODULAR BRUSH GUARD – PART # 869633
03-06 TOYOTA 4Runner

Parts List *(Please check that you have all the parts listed below before you start installing)*

Quantity	Description
2	Mounting brackets
4	M12 U-bolts
6	M12X40 (19mm hex head bolts)
14	M12 Nylon lock nuts (19mm socket nuts)
20	½" Washers

Installation of Mounting Frame Brackets & Brush Guard

1. Identify left and right brackets to be used (D for driver side / P for passenger side).
2. Insert U-bolts from top of the mainframe vertically and under mainframe horizontally thru supplied bracket, loosely fasten with supplied nuts and washers.



3. Repeat procedure on the opposite side.
4. With the help of another person, install Brush Guard to brackets with supplied nuts and bolts and washers.
5. Adjust and securely tighten all bolts and nuts.

**For technical support, please call
1-510-567-8875**